Knee Cup Replacement

1. Remove lower cuff liner

2. Remove velcro hook that is covering clip.

3. Use a pair of long nose pliers to remove clip.

4. Pull clip as shown above.

5. Remove pin that holds Knee cup in place

6. Slide knee cup out of slot.

To attach knee cup, reverse steps as follows:

1. Slide knee cup into slot.
2. Replace pin into hole (holds knee cup in place).
3. Replace clip to secure pin.
4. Replace the velcro hook to cover clip.
5. Place lower cuff liner into proper position.

*** Note: Please refer to manual for the tension strap attachment.**